

Cabinet and cart interiors with LED lights improve visibility to supplies in departments throughout a hospital and are especially useful in hybrid ORs with dimmed overhead lighting. The LED interior lighting can be installed on all Roam carts and Evolve tall, upper, and scope cabinets with hinged doors.



- Lights run from the base to the top of the cabinet or cart.
- LEDs remain lit. Our customer service representatives can work with you to provide a custom solution that allows you to turn the lights on and off.
- The lights are hardwired; power cord is 10' long.
- Power entry on Roam carts is on the back of the cart top.
- Power entry on Evolve cabinets is through the cabinet top.

Lighting Details

- LED driver input voltage – 12VDC or 24VDC
- LED color – Cool White 6000k
- Average lifespan – 50,000 hours
- UL listed
- RoHS compliant

Power consumption

Product	Total power consumption (watts)
Roam 1 carts	16
Roam 2 carts	16
Roam 3 carts	32
Roam 4 carts	32
Evolve tall and upper cabinets.....	20
Evolve scope cabinets.....	22